

**OPERATING INSTRUCTIONS FOR 'ELLF' ELECTRONIC LABEL LEVEL FINDER
WITH STEPPER MOTOR TYPE LABEL FEED DRIVE (SERIES 'V' MACHINES)**

1. TO SET THE HEIGHT OF THE LABEL STACK, ADJUST THE FIBER OPTIC SENSOR UP OR DOWN FOR DESIRED LABEL HEIGHT. 'ELLF' WILL NOW MAINTAIN THE PROPER HEIGHT OF THE LABEL STACK WITHOUT HAVING TO DEPEND ON THE CONTAINERS TO TRIP THE MECHANICAL "LABEL FEED CONTROL BLOCKS". THIS SETTING SHOULD NOT HAVE TO VARY, UNLESS WHEN CHANGING FROM SMALL TO LARGE OR LARGE TO SMALL DIAMETER CONTAINERS AND LABEL PICK-UP PROBLEMS OCCUR.

NOTE: SENSOR SHOULD BE SET IN AS CLOSE AS POSSIBLE TO THE LABEL STACK WITHOUT TOUCHING THE LABEL STACK. (APPROX. 1/16" TO 3/32")

2. TO LOWER THE LABEL BED WHEN REFILLING WITH LABELS, SHUT OFF THE AIR SUPPLY TO THE AIR CLUTCH WITH THE HAND OPERATED VALVE AND LOWER THE LABEL BED BY TURNING THE HANDWHEEL. AFTER REFILLING WITH LABELS, RAISE THE LABEL BED TO THE APPROXIMATE HEIGHT, TURN ON THE AIR SUPPLY TO THE AIR CLUTCH WITH THE HAND OPERATED VALVE, AND 'ELLF' WILL RAISE THE LABEL STACK TO THE PRESET HEIGHT.

3. A SECOND FIBER OPTIC SENSOR, LOCATED JUST UNDER THE REAR SIDE LABEL GUIDE CASTING, IS FOR SENSING THE PRESENCE OF LABELS IN THE LABEL BED. THIS SENSOR ALLOWS THE 'ELLF' DRIVE TO OPERATE ONLY AFTER LABELS ARE PLACED INTO THE LABEL BED AND THE LABEL BED IS RAISED SO THAT THE LABELS TRIP THE SENSOR. AT THIS TIME 'ELLF' WILL OPERATE TO MAINTAIN THE PROPER LABEL STACK HEIGHT. ALSO THIS SENSOR WILL STOP THE 'ELLF' DRIVE PRIOR TO THE LABEL BED RUNNING OUT OF LABELS. THIS HAPPENS WHEN THE LABEL BED RAISES TO THE POINT WHERE THE SENSOR WILL SENSE THE HOLE LOCATED IN THE OUTSIDE LABEL SUPPORT PLATE.

NOTE: SENSOR SHOULD BE SET APPROXIMATELY 1/4" FROM THE LABEL STACK AND THE SENSITIVITY SHOULD BE ADJUSTED SO THAT WHEN THE HOLE IN THE OUTSIDE LABEL SUPPORT PLATE IS AT THE SENSOR HEIGHT THE SENSOR DOES NOT SENSE THROUGH THE HOLE TO THE CENTER LABEL PLATE SUPPORT.

NOTE: THE LABEL BED WILL REQUIRE TO HAVE AT LEAST AN APPROXIMATE MINIMUM OF 1-1/2" STACK OF LABELS IN THE BED FOR 'ELLF' TO OPERATE.

NEW WAY PACKAGING MACHINERY, INC.
P.O. BOX 467 210 BLETNER AVENUE
HANDOVER, PA. 17331
TEL. (717) 637-2133 OR 637-8998
FAX. (717) 637-2966 WEB SITE: www.labeler.com