



DWG. NO. NAL-A21LCT
 MODEL A7 LABELER
 CONTINUOUS FEED (TOGGLE FINGER TYPE)
 LABEL FEED DRIVE ASSFMRI Y

MODEL A7 LABELER CONTINUOUS FEED (TOGGLE FINGER TYPE) LABEL FEED DRIVE ASSEMBLY
 DWG. NO. NAL-A21LCT

ITEM NO.	PART NO.	DESCRIPTION
1	NAL-2901	LABEL FEED SUPPORT PLATE
2	NAL-2904	LABEL FEED SUPPORT SPACER
3	NLE-B122012	BEARING
4	NLEBIR081212	INNER RACE
5	NLE-AC229	CONTROL LABEL FEED GEAR ASSEMBLY
6	NLE-BB1416/8	BRONZE BUSHING
7	FP-SC14	SET COLLAR
8	NLE-2102	MANUAL CONTROL GEAR
9	NLE-A243RHS	LABEL FEED RACK SUPPORT ASSY. (INCLUDES ITEM #10)
10	NLE-2251	BRONZE BUSHING
11	NAL-2903	LABEL FEED SUPPORT BRACE
12	FP-SC12	SET COLLAR
13	NLE-2100	LABEL FEED ADJUST SHAFT
14	NLE-AC2148	HAND WHEEL ASSEMBLY (INCLUDES ITEM #15)
15	NL-4102A	STEEL CRANK HANDLE
16	F-SH08F36	SOCKET HEAD CAP SCREW
17	NLE-243LHS	LABEL FEED RACK SUPPORT
18	NLE-C2152	BRONZE BUSHING
19	NLE-C2123A	LABEL FEED CLUTCH MEMBER-F.E.
20	NLE-AC226A	FEED SHAFT SUPP. BKT. ASSY. (INCLUDES ITEM #18-#35)
21	NLE-C235	LABEL FEED CLUTCH ROLLER
22	NLE-C2125	CLUTCH ROLLER STUD
23	NLE-C2122	LABEL FEED CLUTCH MEMBER-F.E.
24	NLE-C2146	BRONZE BUSHING
25	NLE-AC2145	CLUTCH LEVER SUPPORT ASSY. (INCLUDES ITEM #24)
26	NLE-C2126	CLUTCH SUPPORT STUD
27	NLE-C2127	LABEL FEED CLUTCH COLLAR
28	NLE-639	CLUTCH LEVER SUPPORT SHAFT
29	NLE-C223	LABEL FEED CLUTCH MEMBER-D.E.
30	NLE-C222A	LABEL FEED CLUTCH MEMBER-D.E.
31	NAL-2919	LABEL FEED SHAFT SUPPORT
32	NAL-215LCT	CONTINUOUS LABEL FEED CONTROL SHAFT
33	NLE-C2128	WASHER
34	NLE-C2143	LABEL FEED CLUTCH KEY
35	NLE-C234A	SHAFT SUPPORT BRACKET BUSHING
36	NLE-C228A	LABEL FEED GEAR SPACER
37	F-SH04C32	SOCKET HEAD CAP SCREW
38	NL-47L	EXTENSION SPRING
39	NAL-2906	CLUTCH LEVER RETAINER
40	NLE-C2138	CLUTCH LEVER RETAINER BAR
41	NLE-C227	LABEL FEED CLUTCH LEVER
42	NAL-2169	END FEED BAR GUIDE
43	NAL-2165L	AUXILIARY FEED BAR
44	NLE-A2549	TOGGLE FINGER BLOCK ASSY.
45	NA-2173	AUXILIARY FEED BAR GUIDE ROD

WHEN ORDERING REPAIR PARTS, GIVE MODEL NO., MACHINE NO. & SERIAL NO.
 AS WELL AS PART NUMBER AND NAME.

NEW WAY PACKAGING MACHINERY, INC.
 P.O. BOX 467 210 BLETTNER AVENUE
 HANOVER, PA. 17331
 TEL. (717) 637-2133 OR 637-8998
 FAX. (717) 637-2966 WEB SITE: www.labeler.com

DECEMBER 15, 2002

MODEL A7 LABELER CONTINUOUS FEED (TOGGLE FINGER TYPE) LABEL FEED DRIVE ASSEMBLY
DWG. NO. NAL-A21LCT

ITEM NO.	PART NO.	DESCRIPTION
46	NAL-2172	FEED BAR ADJUSTMENT GUIDE
47	NAL-2164	AUXILIARY FEED BAR SUPPORT
48	NLE-238L__	LABEL PLATE - #14 (3-1/2") THRU #28 (7") - 1/4" INCREMENTS
	NLE-238S__	LABEL PLATE - #09 (2-1/4") THRU #13 (3-1/4") - 1/4" INCREMENTS
49	NA-236LHS	CENTER LABEL PLATE SUPPORT
50	NA-4333	ARM BUSHING
51	NA-202	SUPPORT MOUNT PLATE - FRONT
52	NA-203	SUPPORT MOUNT PLATE - BACK
53	NA-206LHS	LABEL BED SUPPORT
54	NA-204	SUPPORT GUIDE PLATE - FRONT
55	NA-205	SUPPORT GUIDE PLATE - BACK
56	NLE-2103HS	LABEL FEED RACK
57	NA-W207HS	ADJUSTING SCREW - PRIMARY FEED
58	NA-229	SWITCH TRIP BAR
59	NA-230	TRIP BAR SPACER
60	F-SH06C16	SOCKET HEAD CAP SCREW
61	NA-2166	AUXILIARY FEED ADJUST SHAFT
62	NA-2178	3/4" BEARING SEAL
63	NA-2179	3/4" BEARING RETAINER RING
64	NA-2180	3/4" BALL BEARING
65	NA-2168	BEARING HOUSING
66	NAL-206CF	AUXILIARY LABEL BED SUPPORT
67	NL-47S	EXTENSION SPRING
68	NLE-1032	TRIP VALVE ARM EXTENSION
69	NLE-1038	TRIP VALVE
70	NLE-1031	TRIP VALVE MOUNT PLATE

WHEN ORDERING REPAIR PARTS, GIVE MODEL NO., MACHINE NO. & SERIAL NO.
AS WELL AS PART NUMBER AND NAME.

NEW WAY PACKAGING MACHINERY, INC.
P.O. BOX 467 210 BLETTNER AVENUE
HANOVER, PA. 17331
TEL. (717) 637-2133 OR 637-8998
FAX. (717) 637-2966 WEB SITE: www.labeler.com

PAGE 2 OF 2