



DWG. NO. NAL-A21SCTRC
 MODEL ASRC L.H. CONTROL LABELER
 CONTINUOUS FEED (TOGGLE FINGER TYPE)
 LABEL FEED DRIVE ASSEMBLY

REVISION 10, 2001

MODEL ASRC L.H. CONTROL LABELER
CONTINUOUS FEED (TOGGLE FINGER TYPE) LABEL FEED DRIVE ASSEMBLY
DWG. NO. NAL-A21SCTRC

ITEM NO.	PART NO.	DESCRIPTION
1	NAL-2901	LABEL FEED SUPPORT PLATE
2	NAL-2904	LABEL FEED SUPPORT SPACER
3	NLE-B122012	BEARING
4	NLEBIR081212	INNER RACE
5	NLE-AC229	CONTROL LABEL FEED GEAR ASSEMBLY
6	NLE-BB1416/8	BRONZE BUSHING
7	FP-SC14	SET COLLAR
8	NLE-2102	MANUAL CONTROL GEAR
9	NLE-A243RHS	LABEL FEED RACK SUPPORT ASSY. (INCLUDES ITEM #10)
10	NLE-2251	BRONZE BUSHING
11	NAL-2903	LABEL FEED SUPPORT BRACE
12	FP-SC12	SET COLLAR
13	NLE-2100	LABEL FEED ADJUST SHAFT
14	NLE-AC2148	HAND WHEEL ASSEMBLY (INCLUDES ITEM #15)
15	NL-4102A	STEEL CRANK HANDLE
16	F-SH08F36	SOCKET HEAD CAP SCREW
17	NLE-243LHS	LABEL FEED RACK SUPPORT
18	NLE-C2152	BRONZE BUSHING
19	NLE-C222A	LABEL FEED CLUTCH MEMBER
20	NLE-AC226A	FEED SHAFT SUPP. BKT. ASSY. (INCLUDES ITEM #18-#35)
21	NLE-C235	LABEL FEED CLUTCH ROLLER
22	NLE-C2125	CLUTCH ROLLER STUD
23	NLE-C223	LABEL FEED CLUTCH MEMBER
24	NLE-C2146	BRONZE BUSHING
25	NLE-AC2145	CLUTCH LEVER SUPPORT ASSY. (INCLUDES ITEM #24)
26	NLE-C2126	CLUTCH SUPPORT STUD
27	NLE-C2127	LABEL FEED CLUTCH COLLAR
28	NLE-639	CLUTCH LEVER SUPPORT SHAFT
29	NLE-C2122	LABEL FEED CLUTCH MEMBER
30	NLE-C2123A	LABEL FEED CLUTCH MEMBER
31	NAL-2919	LABEL FEED SHAFT SUPPORT
32	NAL-215SCT	CONTINUOUS LABEL FEED CONTROL SHAFT
33	NLE-C2128	WASHER
34	NLE-C2143	LABEL FEED CLUTCH KEY
35	NLE-C234A	SHAFT SUPPORT BRACKET BUSHING
36	NLE-C228A	LABEL FEED GEAR SPACER
37	F-SH04C32	SOCKET HEAD CAP SCREW
38	NL-47L	EXTENSION SPRING
39	NAL-2906	CLUTCH LEVER RETAINER
40	NLE-C2138	CLUTCH LEVER RETAINER BAR
41	NLE-C227	LABEL FEED CLUTCH LEVER
42	NAL-2169	END FEED BAR GUIDE
43	NAL-2165S	AUXILIARY FEED BAR
44	NLE-A2549	TOGGLE FINGER BLOCK ASSY.
45	NA-2173	AUXILIARY FEED BAR GUIDE ROD

WHEN ORDERING REPAIR PARTS, GIVE MODEL NO., MACHINE NO. & SERIAL NO.
AS WELL AS PART NUMBER AND NAME.

NEW WAY PACKAGING MACHINERY, INC.
P.O. BOX 467 210 BLETNER AVENUE
HANOVER, PA. 17331
TEL. (717) 637-2133 OR 637-8998
FAX. (717) 637-2966 WEB SITE: www.labeler.com

MODEL ASRC L.H. CONTROL LABELER
 CONTINUOUS FEED (TOGGLE FINGER TYPE) LABEL FEED DRIVE ASSEMBLY
 DWG. NO. NAL-A21SCTRC

ITEM NO.	PART NO.	DESCRIPTION
46	NAL-2172	FEED BAR ADJUSTMENT GUIDE
47	NAL-2164	AUXILIARY FEED BAR SUPPORT
48	NLE-238S__	LABEL PLATE - #09 (2-1/4") THRU #28 (7") - 1/4" INCREMENTS
49	NA-236SHS	CENTER LABEL PLATE SUPPORT
50	NA-4333	ARM BUSHING
51	NA-202	SUPPORT MOUNT PLATE - FRONT
52	NA-203	SUPPORT MOUNT PLATE - BACK
53	NA-206SHS	LABEL BED SUPPORT
54	NA-204	SUPPORT GUIDE PLATE - FRONT
55	NA-205	SUPPORT GUIDE PLATE - BACK
56	NLE-2103HS	LABEL FEED RACK
57	NA-W207HS	ADJUSTING SCREW - PRIMARY FEED
58	NA-229	SWITCH TRIP BAR
59	NA-230	TRIP BAR SPACER
60	F-SH06C16	SOCKET HEAD CAP SCREW
61	NA-2166	AUXILIARY FEED ADJUST SHAFT
62	NA-2178	3/4" BEARING SEAL
63	NA-2179	3/4" BEARING RETAINER RING
64	NA-2180	3/4" BALL BEARING
65	NA-2168	BEARING HOUSING
66	NAL-206CF	AUXILIARY LABEL BED SUPPORT
67	NL-47S	EXTENSION SPRING
68	NLE-1032	TRIP VALVE ARM EXTENSION
69	NLE-1038	TRIP VALVE
70	NLE-1031	TRIP VALVE MOUNT PLATE

WHEN ORDERING REPAIR PARTS, GIVE MODEL NO., MACHINE NO. & SERIAL NO.
 AS WELL AS PART NUMBER AND NAME.

NEW WAY PACKAGING MACHINERY, INC.
 P.O. BOX 467 210 BLETTNER AVENUE
 HANOVER, PA. 17331
 TEL. (717) 637-2133 OR 637-8998
 FAX. (717) 637-2966 WEB SITE: www.labeler.com