



MODEL A5RC/A7RC/APRC L.H. CONTROL LABELER GUM POT ASSEMBLY
DWG. NO. NAL-A31RC

ITEM NO.	PART NO.	DESCRIPTION
1	NLE-A326	ROCKER ARM BRACKET ASSEMBLY (INCLUDES ITEM #16)
2	F-SP5/32-24	SPRING PIN
3	NL-A334	TOP GUM ROLL SHAFT ASSEMBLY (INCLUDES ITEM #2)
4	NLE-3181	GUM POT LID STUD
5	NLE-321	GUM POT LID HANDLE
6	NLE-319A	GUM POT LID
7	NLE-A31/P	GUM POT BASE (INCLUDES ITEM #16)
8	NA-PF14	1/2" NPT BRASS PIPE PLUG
9	NLE-320	GUM POT THERMOMETER
10	FP-SQ06C28	SQUARE HEAD SET SCREW
11	NLE-335	TOP GUM ROLL SCRAPER
12	NLE-313/2A	CENTER GUM ROLL RETAINER PLATE
13	NLE-313/3	GUM ROLL RETAINER PLATE - SQUAT CANS
14	NL-325/1	ADJUSTABLE CENTER GUM ROLL KEY
15	NLE-316	SIDE SCRAPER ADJUST CLIP
16	NLE-340	BRONZE BUSHING
17	FP-TS04C12	THUMB SCREW
18	NLE-A338	FEED ROLL ASSEMBLY (INCLUDES ITEMS #16 & #29)
19	NLE-336B	BOTTOM GUM ROLL SCRAPER
20	NLE-3207B	RUBBER GUM ROLL DISC - FORM D
21	NLE-A355B	OUTSIDE GUM ROLL ASSEMBLY - FORM D
22	NLE-A356B	CENTER GUM ROLL ASSEMBLY - FORM D
23	NLE-333E	BRASS GUM ROLL DISC - FORM C
24	NLE-A332	OUTSIDE GUM ROLL ASSEMBLY - FORM C
25	NLE-A333B	CENTER GUM ROLL ASSEMBLY - FORM C
26	NLE-A333SQ	CENTER GUM ROLL ASSEMBLY - SQUAT CANS
27	NLE-38	FEED ROLL SHAFT SPUR GEAR
28	F-WK07	WOODRUFF KEY
29	NLE-339	FEED ROLL SHAFT
30	NL-47H	EXTENSION SPRING
31	NLE-324	ROCKER ARM SPRING STUD

WHEN ORDERING REPAIR PARTS, GIVE MODEL NO., MACHINE NO. & SERIAL NO.
AS WELL AS PART NUMBER AND NAME.

NEW WAY PACKAGING MACHINERY, INC.
P.O. BOX 467 210 BLETTNER AVENUE
HANOVER, PA. 17331
TEL. (717) 637-2133 OR 637-8998
FAX. (717) 637-2966 WEB SITE: www.labeler.com