



SECTION A-A

DWG. NO. NLE-A18L
 MODEL E7/EP LABELER
 DISCHARGE END COLUMN
 SUPPORT AND DRIVE ASSEMBLY

MODEL E7/EP LABELER DISCHARGE END COLUMN SUPPORT AND DRIVE ASSEMBLY
 DWG. NO. NLE-A18L

ITEM NO.	PART NO.	DESCRIPTION
1	NLE-5303	OVERHEAD CARRIER ARM KEY
2	NLE-560	OVERHEAD CARRIER BAR
3	NLE-559D	OVERHEAD CARRIER ARM - D.E.
4	NLE-5333	CARRIER ARM CAP - D.E.
5	NLE-BS8F	BEARING
6	NLE-W111	COLUMN CROSS TIE ROD
7	NLE-155	SUPPORT BRACKET
8	NLE-18	COLUMN COVER PLATE
9	NLE-17L	FRONT MAIN COLUMN - D.E.
10	NLE-124	COLUMN COVER PLATE
11	NAL-561	SUPPORT SHIELD
12	NLE-597A	COLUMN DRIVE SHAFT - D.E.
13	NA-PF10	1/8" NPT B.I. PIPE PLUG
14	NLE-126	COLUMN CLAMP BUSHING
15	NLE-A51	REDUCTION HOUSING ASSEMBLY
16	NLE-56	COLUMN COVER PLATE
17	NA-PF12	3/8" NPT B.I. PIPE PLUG
18	NA-PF18	1/2-3/8 NPT B.I. PIPE BUSHING
19	NLE-520	TUBING THRUST COLLAR
20	NLE-543	THRUST WASHER
21	NLE-537	REAR MAIN COLUMN GUARD
22	NLE-110/L	REAR MAIN COLUMN - D.E.
23	NLE-516	COLUMN DRIVE TUBING - D.E.
24	NLE-592	PASTE POT DRIVE MITER GEAR
25	F-WK09	WOODRUFF KEY
26	NLE-591	PASTE POT DRIVE GEAR
27	NLE-5302	COLUMN DRIVE TUBE KEY
28	NLE-BS11RF	BEARING
29	NLE-517L/L	DIAMETER ADJUST SCREW - D.E. - L.H.
30	NLE-521	DIAMETER ADJUST BEVEL GEAR
31	F-WK07	WOODRUFF KEY
32	NLE-519	THRUST ADJUST NUT
33	FP-HN08F	PLATED HEX NUT
34	NLE-518L	DIAMETER ADJUST SCREW SLEEVE - D.E. - L.H.
35	NLE-595	DRIVE GEAR
36	NLE-599	MAIN DRIVE SPUR GEAR - 84T
37	NLE-566	COUNTER DRIVE SHAFT KEY
38	NLE-55	REDUCTION HOUSING COVER
39	NLE-OS221	OIL SEAL
40	NL-B2230	BEARING
41	NLE-510	REDUCTION COVER CAP
42	NLE-BFS180X1	BEARING
43	NLE-OS219	OIL SEAL
44	NLE-532	BEARING RETAINER BUSHING

WHEN ORDERING REPAIR PARTS, GIVE MODEL NO., MACHINE NO. & SERIAL NO.
 AS WELL AS PART NUMBER AND NAME.

NEW WAY PACKAGING MACHINERY, INC.
 P.O. BOX 467 210 BLETTNER AVENUE
 HANDOVER, PA. 17331
 TEL. (717) 637-2133 OR 637-8998
 FAX. (717) 637-2966 WEB SITE: www.labeler.com

MODEL E7/EP LABELER DISCHARGE END COLUMN SUPPORT AND DRIVE ASSEMBLY
DWG. NO. NLE-A18L

ITEM NO.	PART NO.	DESCRIPTION
45	NLE-522	DIAMETER ADJUST BEVEL PINION
46	F-WK11	WOODRUFF KEY
47	NLE-OS147	OIL SEAL
48	NLE-453	ADJUST WASHER
49	NLE-OS353	OIL SEAL
50	NLE-5341	COUNTER DRIVE SHAFT SCREW
51	NLE-596	DRIVE GEAR
52	NLE-5101	DRIVE SHAFT - 14 TEETH
53	NLE-OS89	OIL SEAL
54	NLE-540	DRIVE HOUSING CAP
55	NLE-529L	INTERMEDIATE ADJUST SHAFT - D.E.
56	NLE-538A	DIAMETER ADJUST SHAFT SUPPORT
57	NS-143	SPLIT SHAFT COUPLING

WHEN ORDERING REPAIR PARTS, GIVE MODEL NO., MACHINE NO. & SERIAL NO.
AS WELL AS PART NUMBER AND NAME.

NEW WAY PACKAGING MACHINERY, INC.
P.O. BOX 467 210 BLETTNER AVENUE
HANDOVER, PA. 17331
TEL. (717) 637-2133 OR 637-8998
FAX. (717) 637-2966 WEB SITE: www.labeler.com