



DWG. NO. NLE-A216
 MODEL E5/E7/EP LABELER
 ABEL FEED DRIVE ASSEMBLY

MODEL E5/E7/EP LABELER LABEL FEED DRIVE ASSEMBLY
DWG. NO. NLE-A216

ITEM NO.	PART NO.	DESCRIPTION
1	NLE-266A	FEED CONTROL LEVER
2	NLE-2106	FEED CONTROL ROD CONNECTOR
3	NLE-262B	LABEL FEED CONTROL ROD
4	NLE-W2301	TRIP ROD GUIDE
5	NLE-A265C	LABEL FEED CONTROL ROD ASSEMBLY
6	NLE-279	ECCENTRIC BUSHING HOUSING
7	FP-JN08F/LH	PLATED JAM NUT - LEFT HAND
8	NL-1641	GREASE FITTING - SHORT
9	NLE-280	ECCENTRIC BUSHING WASHER
10	FP-JN08F	PLATED JAM NUT
11	NLE-281	ECCENTRIC CONNECTING ROD
12	NLE-A250L	RATCHET PAWL ASSY. - L.H.
13	NLE-282	CONNECTING ROD CONNECTOR
14	NLE-271	FEED CONTROL PIN HOUSING
15	NLE-2278A	COMPRESSION SPRING
16	NLE-A272	FEED CONTROL PAWL ASSY.
17	NLE-269	DETENSION PAWL SPRING STUD
18	NLE-255	BELL CRANK SPRING STUD
19	FP-SQ05C08	PLATED SQUARE HEAD SET SCREW
20	NLE-267	DETENSION PAWL STUD
21	NL-328H	EXTENSION SPRING
22	F-SH05C24	SOCKET HEAD CAP SCREW
23	NLE-W253	CONTROL DISC CRANK
24	NLE-254	BELL CRANK BUSHING
25	NLE-A250R	RATCHET PAWL ASSY. - R.H.
26	NL-289L	EXTENSION SPRING
27	NLE-256	CONNECTING ROD ROCKER ARM PIN
28	NLE-249	RATCHET PAWL STUD
29	NLE-251	CONNECTING ROD ROCKER ARM
30	FP-SC14	SET COLLAR
31	NLE-246	RATCHET WHEEL
32	NLE-A247A	PAWL CONTROL DISC ASSY. (INCLUDES ITEM #33, & #34)
33	NLE-248	CONTROL DISC SPACER
34	NLE-252	BELL CRANK FILLER

WHEN ORDERING REPAIR PARTS, GIVE MODEL NO., MACHINE NO. & SERIAL NO.
AS WELL AS PART NUMBER AND NAME.

NEW WAY PACKAGING MACHINERY, INC.
P.O. BOX 467 210 BLETTNER AVENUE
HANDOVER, PA. 17331
TEL. (717) 637-2133 OR 637-8998
FAX. (717) 637-2966 WEB SITE: www.labeler.com