



DWG. NO. NLE-A68
 MODEL A5RC/A7RC/APRC - E5RC/E7RC/EPRC
 L.H. CONTROL LABELER
 PASTE POT ASSEMBLY - BRONZF

MODEL A5RC/A7RC/APRC - E5RC/E7RC/EPRC L.H. CONTROL LABELER
 PASTE POT ASSEMBLY - BRONZE

DWG. NO. NLE-A68

ITEM NO.	PART NO.	DESCRIPTION
1	NLE-3157	PASTE POT WORM SHAFT
2	NLE-3159	WORM SHAFT OILING SCREW
3	NLE-3158	WORM SHAFT BUSHING
4	NLE-A64	BRONZE PASTE POT WITH BUSHINGS (INCLUDES ITEM #3(2)-#5(2)-#16(2))
5	NLE-3144	BRONZE BUSHING
6	F-WK213	WOODRUFF KEY
7	NLE-3118/A	MAIN DRIVE PULLEY SHAFT
8	NLE-3166	MAIN DRIVE SHAFT NUT
9	NLE-3117WB	MAIN DRIVE PULLEY
10	NLE-3101/C	PASTE POT LID
11	NLE-3120L	PASTE POT CAP
12	NLE-3120S	PASTE POT CAP
13	F-SS07F08	SOCKET SET SCREW
14	NA-PF14	1/2" NPT BRASS PIPE PLUG
15	FP-SC08	SET COLLAR
16	NLE-3162	BRONZE BUSHING
17	NLE-3171	PASTE FEED WHEEL SHAFT
18	NL-1641	GREASE FITTING - SHORT
19	NLE-A3156BR	BRONZE PASTE CONV. SCREW ASSY. (INCLUDES ITEM #20(2))
20	NLE-3163	BRONZE BUSHING
21	NLE-3131WA	WIRE BELT SCRAPER
22	NL-1292	FILLER
23	NLE-3122WA	WIRE PASTE BELT - 56'
		(NLE-3122-6 'PACK OF 6 BELTS' OR NLE-3122-25 'PACK OF 25 BELTS')
24	NLE-3327	PASTE SCRAPER BASE - R.C.
25	NLE-3165BR	PASTE SCRAPER RETAINER - BRONZE
26	NLE-3316	PASTE SCRAPER RETAINER SCREW
27	NLE-3172	PASTE POT DRIVEN SPROCKET
28	NLE-3160	PASTE FEED DRIVE GEAR
29	NLE-A3161	PASTE FEED IDLER GEAR ASSY. (INCLUDES ITEM #30(2)-#31)
30	NLE-3167	PASTE FEED IDLER GEAR PIN
31	NLE-3164	BRONZE BUSHING

WHEN ORDERING REPAIR PARTS, GIVE MODEL NO., MACHINE NO. & SERIAL NO.
 AS WELL AS PART NUMBER AND NAME.

NEW WAY PACKAGING MACHINERY, INC.
 P.O. BOX 467 210 BLETTNER AVENUE
 HANOVER, PA. 17331
 TEL. (717) 637-2133 OR 637-8998
 FAX. (717) 637-2966 WEB SITE: www.labeler.com