



DWG. NO. NLE-A80EXP
 MODEL E5/E7/EP LABELER
 ELLF EXPLOSION PROOF AIR MOTOR
 LABEL FEED DRIVE ASSEMBLY

MODEL E5/E7/EP LABELER ELLF EXPLOSION PROOF AIR MOTOR LABEL FEED DRIVE ASSEMBLY
 DWG. NO. NLE-ABOEXP

ITEM NO.	PART NO.	DESCRIPTION
1	NA-ESP11	FIBER OPTIC CABLE
2	NLE-607	FIBER OPTIC ADJUST PLATE
3	NLE-606E	FIBER OPTIC MOUNT PLATE
4	NLE-641	FIBER OPTIC MOUNT PLATE
5	NLE-611	DRIVEN SPROCKET
6	NLE-624	LABEL FEED DRIVE CHAIN
7	NLE-615	SUPPORT PLATE
8	NLE-616	END COVER
9	NLE-266A	FEED CONTROL LEVER
10	NLE-2106	FEED CONTROL ROD CONNECTOR
11	NLE-646	FIBER OPTIC MOUNT CLIP (CONTINUOUS FEED ONLY)
12	FP-HNAC	PLATED HEX NUT
13	NLE-262B	LABEL FEED CONTROL ROD
14	FP-HNAC/LH	PLATED HEX NUT-LEFT HAND
15	NLE-623	CONTROL ROD CLIP
16	NLE-618	DRIVE CHAIN GUARD-BACK
17	NLE-620	GUARD ANGLE CLIP
18	NLE-617	DRIVE CHAIN GUARD-FRONT
19	NLE-619	GUARD ANGLE CLIP
20	NA-PV11	4 WAY VALVE-3/8" HANDLEVER
21	NA-PMOTOR1	PNEUMATIC MOTOR
22	NLE-645	AIR MOTOR CUSHION PAD
23	NA-PEM2	EXHAUST MUFFLER-1/4"
24	NLE-628	MOTOR MOUNT ANGLE
25	NLE-627	DRIVE PULLEY
26	NLE-625	LABEL FEED DRIVE BELT
27	NA-RED3	GEAR REDUCER
28	NLE-609	DRIVEN PULLEY
29	NLE-610	DRIVE SPROCKET
30	NLE-614	GEARBOX MOUNT BLOCK
31	F-SH08F36	SOCKET HEAD CAP SCREW
32	NLE-243L	LABEL FEED RACK SUPPORT
33	NLE-B122012	BEARING
34	NLEBIR081212	INNER RACE
35	NLE-AC229	CONTROL LABEL FEED GEAR ASSEMBLY
36	NFT-286	BRONZE BUSHING
37	FP-SC14	SET COLLAR
38	NLE-638	LABEL FEED CONTROL SHAFT
39	NLE-A243R	LABEL FEED RACK SUPPORT ASSY. (INCLUDES ITEM #41)
40	NLE-2102	MANUAL CONTROL GEAR
41	NLE-2251	BRONZE BUSHING
42	NLE-2100	LABEL FEED ADJUST SHAFT

WHEN ORDERING REPAIR PARTS, GIVE MODEL NO., MACHINE NO. & SERIAL NO.
 AS WELL AS PART NUMBER AND NAME.

NEW WAY PACKAGING MACHINERY, INC.
 P.O. BOX 467 210 BLETTNER AVENUE
 HANOVER, PA. 17331
 TEL. (717) 637-2133 OR 637-8998
 FAX. (717) 637-2966 WEB SITE: www.labeler.com

MODEL E5/E7/EP LABELER ELLF EXPLOSION PROOF AIR MOTOR LABEL FEED DRIVE ASSEMBLY
DWG. NO. NLE-A80EXP

ITEM NO.	PART NO.	DESCRIPTION
43	NLE-2113	BRONZE BUSHING
44	NLE-AC2148	HANDWHEEL ASSEMBLY (INCLUDES ITEM #45)
45	NL-4102A	STEEL CRANK HANDLE
46	FP-HH05C56	PLATED HEX HEAD CAP SCREW
47	NL-47L	EXTENSION SPRING
48	NLE-2137L	CLUTCH LEVER RETAINER - LONG FRAME MACHINE
	NLE-2137S	CLUTCH LEVER RETAINER - SHORT FRAME MACHINE
49	NLE-AC226A	FEED SHAFT SUPP. BKT. ASSY. (INCLUDES ITM #50-#63)
50	NLE-C2152	BRONZE BUSHING
51	NLE-C2123A	LABEL FEED CLUTCH MEMBER-F.E.
52	NLE-AC2145	CLUTCH LEVER SUPPORT ASSY. (INCLUDES ITEM #54)
53	NLE-C2126	CLUTCH SUPPORT STUD
54	NLE-C2146	BRONZE BUSHING
55	FP-SC12	SET COLLAR
56	NLE-639	CLUTCH LEVER SUPPORT SHAFT
57	NLE-C2122	LABEL FEED CLUTCH MEMBER-F.E.
58	NLE-C2127	LABEL FEED CLUTCH COLLAR
59	NLE-C2125	CLUTCH ROLLER STUD
60	NLE-C235	LABEL FEED CLUTCH ROLLER
61	NLE-C2128	WASHER
62	NLE-C2143	LABEL FEED CLUTCH KEY
63	NLE-C234A	BRONZE BUSHING
64	NLE-C228A	LABEL FEED GEAR SPACER
65	NLE-C2138	CLUTCH LEVER RETAINER BAR
66	NLE-C227	LABEL FEED CLUTCH LEVER
67	NLE-A24	LABEL FEED CLUTCH LEVER ASSEMBLY (INCLUDES ITEM #53-#59-#65-#66)

WHEN ORDERING REPAIR PARTS, GIVE MODEL NO., MACHINE NO. & SERIAL NO.
AS WELL AS PART NUMBER AND NAME.

NEW WAY PACKAGING MACHINERY, INC.
P.O. BOX 467 210 BLETTNER AVENUE
HANDOVER, PA. 17331
TEL. (717) 637-2133 OR 637-8998
FAX. (717) 637-2966 WEB SITE: www.labeler.com